BATTERY
12V
C8
C7
C6
-12V
C9
R-TRIM1
INPUT
BUF1TP
BATTERY
INPUT_TP
BUF2TP
R-TRIM2
GAINTP
BATTERY
R1JUMPER R1JUMPER2
RLIMIT
OUTPUT
C4
J1_POWER
J2_POWER
SENSORTP